

SHERWRITE Dry Erase Coating Installation

INSTALLATION of SHERWRITE DRY ERASE COATING

Surface Preparation:

New Construction: New drywall should be primed with two good coats of a high-quality universal primer. Let the primer coat cure 24 hours, then using only a 3/8" nap , shed - free roller apply a coat of a HIGH QUALITY Commercial Interior Paint in an Eggshell finish.

Allow any newly painted wall to cure a minimum of 24 hours before applying the Dry Erase Coating. This is a must or coating will fail.

Existing Painted Wall in Good Condition: Lightly sand surface with 180 – 220 grit, then using a Microfiber cloth, wipe down surface to remove all residue.

The smoother and cleaner the wall surface, the more effective the writing surface will be.

APPLICATION

- ALWAYS STIR the Dry Erase Coating well prior to use as solids may settle to bottom of can. Pour the coating through the supplied strainer into the tray
- Only apply with the provided Foam Roller Cover. A plastic Tray Liner is highly recommended.

Step 1

Pour contents into painters' tray with fresh clean liner, pouring the coating through the provided strainer.

Step 2

Use a vertical Up and Down coating method to spread one loaded roller cover approximately one and a half roller widths on a 9 ft wall. Must use

slight pressure to empty the roller. Starting midway up the wall, move the roller up and down in a vertical pattern to cover about one and a half 9" roller widths by approximately 9 ft high. A uniform THIN coat is required. Do not OVER- APPLY the Coating.

Step 3

Reload the roller cover, and continue down the wall using the same up and down rolling method, being sure to keep a wet edge at all times.

Continually inspect your work to ensure complete coverage and that a solid, level coating has been achieved. It is important to make multiple passes (without reloading the roller) to ensure uniform coverage and even distribution with no heavy spots, holes, or uneven texture left on the surface. Inspect carefully from all angles to ensure the entire surface is well-coated. Repeat process for additional sections. You have 30 minutes to go back if necessary,

Step 4

Allow 5 days for product to cure before use as a writing surface. Recommend the use of EXPO BULLET Markers.

CLEAN UP AND DISPOSAL

Step 1

If saving coating from partially used can, it must be sealed completely AIRTIGHT to avoid product hardening in the can.

Coating must be poured through strainer when reused. Otherwise, let unused coating harden in open container and dispose of in accordance with existing federal, state, and local environmental control laws.

Step 2

Discard all roller covers and tray liners. Do not pour unused coating down the sink or drain. Clean roller frames with standard paint thinner.

